

PowerCap® Infinity®


REPLACEMENT FILTERS AND PREFILTERS

TECHNICAL SPECIFICATION

RESPIRATORY PROTECTION

DIMENSIONS OF FILTER OUTER PACKAGING

Quantity: 10 (Pairs)
Weight: 1.2kg (Approx)




HEIGHT:
155mm

LENGTH:
255mm

WIDTH:
255mm

DIMENSIONS OF PREFILTER OUTER PACKAGING


Quantity: 30 (Pairs)
Weight: 4.1kg (Approx)



HEIGHT:
294mm

LENGTH:
420mm

WIDTH:
360mm



POWERCAP INFINITY®

DIMENSIONS OF FILTER:

Height: 64mm (Approx.)
Width: 134mm (Approx.)
Depth: 42mm (Approx.)
Weight: 107g (Approx. per pair)

DIMENSIONS OF PREFILTER:

Height: 64mm (Approx.)
Width: 134mm (Approx.)
Depth: <1mm (Approx.)
Weight: 1.6g (Approx. per pair)

DIMENSIONS OF PREFILTER CASE:

Height: 64mm (Approx.)
Width: 134mm (Approx.)
Depth: 11mm (Approx.)
Weight: 22.2g (Approx. per pair)

LIMITATIONS OF USE

Protection will only be offered if the PowerCap® Infinity® is fitted correctly

Materials, when in contact with the skin, may cause allergic reactions to susceptible individuals. If this occurs leave the hazard area, remove the mask and seek medical advice

Check airflow with the Test Unit before use. Retest outside of area of use at regular intervals to ensure flow level

Use in well-ventilated areas only, which are not deficient in oxygen and do not contain explosive atmospheres

Ensure the skirt is fitted neatly around the face before entering the hazard area

Do not use where exposure to chemical gases may be experienced

The use by date of the filter is printed on the outside of the cartridge

The working life of the filters depends on many factors including work rate, airflow and concentration of any contaminant in the atmosphere

To obtain maximum workable life from the unit, allow the battery to run down fully before recharging



MANUFACTURING FOR SAFETY
WWW.JSP.CO.UK

UKSALES@JSP.CO.UK
TEL: +44 (0)1993 826050

